
Fig. 8 Bottom view

-C33


-C34


C31



## Fig. 5 Power supply circuit

RESISTORS	R306 R307 R309 R310 R318 R317 R315 R314 R316	R304 R305 R301 R302 R335 R303 R341 R336 R338 R337 R339	R323 R332 R333 R320 R310 R312 R321 R322 R334	R324 R331 R329 R328 R326 R327	
CAPACITORS	C3(7 C318	C305 C306 C307 C308	C316	C301-304 C309-312 C313 C314	
MISC.	D308 TR305 TR306 D309 D316 D310 D306 D315 TR303 D305 TR304 D307	TR307 D3II D3I2 TR308 MR301 D3I3 TR	TR302 D304 D301	D314 D317	
				-1 1	





Y Amplifier circuit Fig. 3 R224 R226 R230 R232 R230 R236 R240 R241 R223 R277 R227 R226 R231 R238 R235 R237 R242 R215 R217 R216 R265 R218 R266 R221 R274 R275 R244 R267 R272 R273 R268 R271 R212 R213 R211 R210 R262 R220 R260 R52 R261 R53 R286 R250 R291 8203 R206 R207 R257 R247 R204 R204 R248 R209 R258 R202 R205 R255 R206 R253 R254 R252 R245 R259 R256 R20 R54 R28 R201 R29 R23 R55 R24 R251 R25 R40 - 45 R46 - 51 R26 R56 R21 R57 R27 R22 R287 R290 #2W3 RESISTORS R276 R283 R225 R278 R249 R234 R270 R281 R222 R282 R280 R284 R285 H288 H289 R292 C210 C237 C208 C236 C211 C214 C215 C237 C206 C207 C301 C303 C22 C26 C24 C28 C530 C209 C212 C220 C25 C21 C27 C23 C 205 C204 CZIT C226 C227 CAPACITORS C240 C234 C231 C232 C235 C229 C246 C242 C245 C218 C244 C219 C 238 D201 D202 D215 D216 L201 L203 L204 L202 0204 0205 TR204 TR205 TR.221 5215 5260 TR205 TB220 \$20 Salak 52198 D206 TR207 TR208 TR200 TR210 TR211 TR209 D207 TR218 D210 D212 D208 D209 D213 D211 TR209 MISC. TR212 TR213 TR 216 TR222 525 526aF 5200B SKB NOTES 150+170V I. COMPONENTS CONTAINED WITHIN DOTTED LINES ARE NOT MOUNTED ON PRINTED 12 0 + 20V CIRCUIT BOARD C214 R250 H229 8230 8239 R240 R241 C243 TOCAT TO CAT +7V TO PIN 16 PINT PIN B 1205 D201 R238 R215 R210 R225 R210 C239 TREOL L203 L204-TR210 TR21 COMPONENTS MOUNTED ON FOR SWITCH FRONT PANEL DETAILS SEE INTERCONNECTION R237 DIAGRAM 820 5210F 52108 RZP TRZQ4 TR203 520 R232 C212 AMPLIFIER TR202 0204 0205 FOR SWITCH! 31 Y, SHIFT DETAILS ISKA SEE INTER-(BNC) )-O 0203 CONNECTION DIAGRAM DAG. No. 8224 R225 R226 R234 AO/5K 2349 Y OUT 022 H213 R203 R204 R205 8249 R235 8202 8220 IY, OFF Y BALL Y GAIN R242 C505 H221 H555 9201 C237 C208 7 Cais 0207 R243 PRINTED CIRCUIT BOARD ASSEMBLY No. 32761 +20V D215 R274 R265 H266 H250 525b R290 R291 R280 TR212 F.278 COMPONENTS MOUNTED ON FRONT PANEL FOR SWITCH TALT IN DETAILS SEE R273 DIAGRAM R279 9201 5260F R283 TR217 TR214 TR222 0 C550 AMPLIFIER TRZIS R53 TR221 TREIN TR213 0-OGRD FOR SWITCH 0 0202 Y, SHIFT (BNC) ODC RZI SEE INTER-R244 C238 DIAGRAM R282 R284 R285 R276 C216 DRG. No. R256 AO/5K 2349 D210 C231 C232 D211 R23 R292 R271 CHOP OUT O24 R263 R253 R254 R255 Y2 0010 C244) R289 R288 R252 G222 Y2 BALT D21.4 C225 R251 -C 510 C235 - C234 C245 -20V

528

SWITCH MARKINGS AS VIEWED FROM FRONT PANEL